



DJI PHANTOM 3 PROFESSIONAL CHECKLIST

1. DJI PHANTOM 3 PRO AIRCRAFT PRE-FLIGHT CHECKLIST

- ☐ Gimbal Clamp (Removed; Stowed)
- Micro SD Card (Installed; Available Space)
- Battery (Installed; Status Check Fully Charged)
- Propeller (Check Condition; Installed Black On Black, White On White)
- CHECK COMPLETE

2. DJI PHANTOM 3 PRO CONTROLLER PRE-FLIGHT CHECKLIST

- ☐ Tablet, Phone (Mounted, Plugged In)
- Sun Shield If Applicable (Mounted, Adjusted)
- Antennas (Positioned)
- Flight Mode Switch (Desired Position)
- Battery (Status Check Fully Charged)
- CHECK COMPLETE

3. DJI PHANTOM 3 PRO CONTROLLER BEFORE ENGINE START CHECKLIST

- ☐ Power On (Controller)
- Battery Status (Double Checked)
- Controller LED (Green)
- Controller Status LED (Checked, No Errors)
- Power On (Tablet, Phone)
- Unnecessary Apps & Features (Exit, Turn Off)
- DJI Pilot App (Launch)
- iPad Mini - Hardware Decode OFF**
- iPhone 6+ - Hardware Decode ON**
- Camera Icon (Select)
- Camera Options (Checked, Set)
- Format SD Card (As Necessary)
- CHECK COMPLETE

4. DJI PHANTOM 3 PRO AIRCRAFT BEFORE ENGINE START CHECKLIST

- ☐ Aircraft (On A Level Surface)
 - Propellers (Double Check Tightness)
 - Power On (Aircraft)
 - Battery (Status Check Fully Charged, No Errors)
 - Compass Calibration (Recommended Prior To Each Flight, Required If Different Launch Site)
 - Interference (Check No Large Metal Surfaces, Cars, Concrete)
 - Ferromagnetic Materials (Check No Keys Or Cell Phone On Person Or Near Aircraft)
 - Proceed With Calibration
 - Return To Home (RTH) Height (Check Proper Height, **PLEASE NOTE RTH HEIGHT IS IN METERS ONLY**)
 - Aircraft Status LED's (Checked, No Errors)
 - Aircraft Orientation (Nose Away From Operator)
 - CHECK COMPLETE

5. DJI PHANTOM 3 PRO TAKEOFF CHECKLIST

- ☐ DJI Pilot App Map (**If Device Data Is Unavailable At Flight Location. Download Map Where Data Is Available**)
 - Home Point (Check Home Point Has Been Set, Manually Set Home Point)
 - Phone/Tablet Volume (Set To Proper Level)
 - Phone/Tablet "Do Not Disturb" (Set If Applicable)
 - DJI Pilot App Flight Status (Check Safe To Fly – GPS, Safe To Fly - VPS)
 - Launch Site (Clear, Safe For Take Off)
 - Start Motors (Both Control Sticks To Lower - Inner Position)
 - Take Off (Auto, Manual)
 - Low Hover (Check Hover Stability)
 - Flight Controls (Move Each Stick Check Proper Stability & Control)
 - CHECK COMPLETE
 - FLY SAFE & ENJOY YOURSELF!!!

Aircraft Status Indicator Quick Reference

N O R M A L		Red, Green and Yellow Flash Alternately	Turning On and Self Diagnostic Testing
		Green and Yellow Flash Alternately	Warming Up
		Green Flashes Slowly	Safe to Fly (P-mode with GPS and Vision Positioning)
		Green Flashes Twice	Safe to Fly (P-mode with Vision Positioning but without GPS)
		Yellow Flashes Slowly	Safe to Fly (A-mode but No GPS and Vision Positioning)
W A R N I N G		Fast Yellow Flashing	Remote Controller's Signal Lost
		Slow Red Flashing	Low Battery Warning
		Fast Red Flashing	Critical Battery Warning
		Red Flashing Alternately	IMU Error
		Solid Red	Solid Red
		Red and Yellow Flash Alternately	Compass Calibration Required

Remote Controller Status Indicator Quick Reference

Status LED	Alarm	Remote Controller Status
————— Solid Red	Chime	The Remote Controller is Disconnected From The Aircraft
————— Solid Green	Chime	The Remote Controller is Connected toThe Aircraft
————— Slow Blinking Red	D-D-D	Remote Controller Error
————— Red & Green/Red & Yellow Alternate Blinks	None	Return-to-home procedure in progress

RTHLED	Sound	Remote Controller Status
————— Solid White	Chime	Aircraft is returning home
————— Blinking White	D . . .	Sending Return-to Home command to the aircraft
————— Blinking White	DD	Return-to-Home procedure in progress