HOW TO: Install Phantom 3 firmware

HOW TO: Install Phantom 3 firmware

Overview

Unlike the Phantom 2 firmware, which was limited to updates to your Phantom 2, remote controller and Phantom batteries, Dronecode Pixhawk Flight Control Board firmware updates, DJI's firmware updates can now update the Phantom 3 Standard, Advanced, Professional and 4K.

Note: Before installing your firmware update, check the forum thread using the **Firmware** tag to see if anyone is having any issues after installing the update. In the days immediately after a new firmware update is released, there are often bugs that are fixed in later updates. Also, if you are having issues with the firmware update, it is the days immediately after a new firmware update is released, there are often bugs that are fixed in later updates. Also, if you are having issues with the firmware update, it is the forum where people will post the solution to your problem.

Download the firmware

Note: If you have a Phantom 3 Standard or Phantom 3 4K, all firmware updates must be installed using the DJI Assistant 2 software. Phantom 3 Advanced and Phantom 3 Professional can use either DJI Assistant 2 or the Phantom app.

DJI Downloads the latest firmware (DJI File Hub) to its download page:

- Phantom 3 Standard firmware
- Phantom 3 Advanced firmware
- Phantom 3 Professional firmware

Important: If you're currently using a firmware version older than 1.0.28, then you must install firmware version 1.0.28 before installing any other firmware. Failure to do so will result in your Phantom 3 not being recognized by the firmware updater.

Note: The Phantom 3 Advanced and Phantom Advanced use different firmware. Make sure you download the correct one.

Note: The Phantom 3 Standard and Phantom 3 Advanced share firmware. Make sure you download the "Firmware Archive" section of Phantom4pro.com.

Install the latest version of DJI GO

In Mid-November, a new firmware update, you should confirm that you're using the most recent version of DJI GO. Firmware updates are pushed through DJI GO, so if you're using an old version of DJI GO, you may not receive firmware updates. Make sure you're using the latest version of DJI GO before installing firmware updates.

Install the firmware on your Phantom

Firmware updates are pushed through DJI GO. Unfortunately, it occasionally a great idea to perform an update through DJI GO. Firmware updates can be pushed to your Phantom 3 while it's in the middle of a controller overhead and becomes damaged when the Phantom is coming into with the ground. Not good at all.

Instead, you should use the Phantom Assistant app for DJI's firmware updates. This ensure you can fly/hover/land/shut-down/restart the **power button**. If needed, stop and restart your remote controller and Phantom.

Activate your Phantom and connect the Phantom to your computer using the **USB cable**.

Turn/reboot the phone or **tablet/laptop** from your Phantom.

Connect the Phantom to the Phantom Assistant app.

Activate the Phantom battery into your Phantom and power on. To power on the battery, press the battery power button once, then press and hold the battery power button for 2 seconds. Wait for the battery to power on and connect to your Phantom.

- Flash power while you Phantom is starting up.
- Wait for the Phantom to finish its initial boot up. Your Phantom's battery needed to be charged to at least 30% before you can update the firmware. Your Phantom's battery needed to be charged to at least 30% before you can update the firmware.

Open the Phantom Assistant app and select Flash firmware (where you can flash your Phantom's firmware). Select the firmware you want to flash. Select the firmware you want to flash (select all if Flash Phase and wait for the camera **gimbal** to turn back on). Wait for the firmware to finish flashing. Wait for the firmware to finish flashing. Do not touch anything while the firmware is flashing.

Wait for the firmware to finish flashing. Do not touch anything while the firmware is flashing.

DJI GO: Install the firmware update on your remote controller using the **Phantom 3 app**.

Disconnect the Phantom from your computer.

Turn/reboot the Phantom.

Turn/reboot your remote controller.

Wait for the firmware to finish flashing. Do not touch anything while the firmware is flashing.

Install the firmware on your remote controller using the DJI GO app

Install the latest version of the DJI GO app on your mobile device. If you have an Apple device, you can download the latest version of DJI GO from the App Store. If you have an Android device, you can download the latest version of DJI GO from the Google Play store.

DJI Tips: In your remote controller. To power on the remote controller, press and release the power button once, then press and hold the power button for 2 seconds.

Wait for your remote controller to power on. Wait for your remote controller to power on.

Connect your remote controller to your mobile device using the **USB cable**. Connect your remote controller to your mobile device using the **USB cable**.

DJI Tips: In your **tablet/laptop**.

Wait for your **tablet/laptop** to boot up. Wait for your **tablet/laptop** to boot up, remove your connected Wait for your **tablet/laptop** to boot up, remove your connected cable from your **tablet/laptop**.

DJI Tips: Connect your **tablet/laptop** to your **remote controller**.

DJI Tips: Connect your **tablet/laptop** to your **remote controller**.

DJI Tips: Open the Phantom Assistant app.

DJI Tips: Open the Phantom Assistant app.

DJI GO: Open the DJI app. Open the DJI app.

DJI GO: Wait for the **Phantom 3 app** to load. Wait for the **Phantom 3 app** to load