HOW TO: Install Phantom 3 firmware

Follow

Author: Nicholas
Posts: 1,111
Joined: Jan 2015
Reputation: 0

HOW TO: Install Phantom 3 firmware

Overview

This tutorial will show you how to install firmware on your Phantom 3, version controller, and Phantom batteries. It focuses on those who have had to go backwards. Carefully read what you will be doing and follow the instructions closely.

Before installing any firmware update, check the release notes to see what is changing and if you are running a newer version than the update. This is the best way to prevent yourself from having to go backwards in the first place.

Also, before installing any firmware update, check the Phantom 3 Firmware Version Matrix to see if you are running a supported version of firmware for your Phantom 3 and controller.

Download the firmware

Note: If you have a Phantom 3 Professional or 4K, all firmware updates must be installed through DJI Assistant 2. Please see the Phantom 3 Professional / 4K section for more information.

DJI downloads the latest firmware DJI Tele Go 2 to download page.

Important: If you're currently running a beta version older than 3.3.38, then you must install 3.3.38 before you can install any newer version. Failure to do so will result in your aircraft not being recognized.

Note: The Phantom 3 Advanced and Phantom Advanced use different firmware. Make sure you download the correct one.

Once you've downloaded the firmware, unzip it and you should see a folder named "WM220_FW_V01.xx.xx.xx" (where "xx.xx.xx.xx" is the version number). Open the folder and you should see a file named "dji_system.bin". Leave this file as it is.

Note: If you're planning to update your Phantom, but not all firmware updates need to be installed, you can download all versions of firmware at once. Just make sure you install them in the order listed in the Phantom 3 Firmware Version Matrix.

- Phantom 3 Standard firmware
- Phantom 3 Professional / 4K firmware
- Phantom 3 Advanced and Phantom Advanced firmware

Prepare your memory card

Delete all files from your memory card or format it.

Note: If you're updating to version 3.3.38 or higher, DJI always ensures the file fits and you may not need to format your memory card.

Install the firmware on your Phantom

Turn on your Phantom and connect it to your computer. A mounted, re-usable or green flash is shown on the aircraft's LED. Open the mounted drive and copy the "dji_system.bin" file you downloaded earlier to the root directory. Make sure the file is copied directly to the root directory of your memory card and not in a folder.

Safely eject your memory card from your computer and insert it into your Phantom. Power on your Phantom and wait for the update process to complete. The process is complete when the LED on the aircraft is solid green.

Power off your Phantom and remove your memory card.

Install the firmware on your remote controller using the DJI GO app

Install the latest version of the DJI GO app on your mobile device. If you have an Apple device, make sure you're running iOS 8.0 or higher. If you have an Android device, make sure you're running Android 4.1.2 or higher. Please see this post for more information.

Note: If you run version controller 3 or above on the remote controller, you must update the firmware through DJI Assistant 2. Please see the Phantom 3 Professional / 4K section for more information.

Note: If you're updating to version 3.3.38 or higher, you must update the firmware through DJI Assistant 2. Please see the Phantom 3 Professional / 4K section for more information.

DJI has the download the firmware update process to the Internet. Once downloaded, the update process will begin automatically. Please see this post for more information on the DJI GO app.

Note: The only controller version that is not listed in the Phantom 3 Firmware Version Matrix is version 1.0.0.0. If you're running this version, you can update to any version listed in the matrix.

Turn on your remote controller and connect your mobile device to it. Open the DJI GO app and log in to your account. If you're updating to version 3.3.38 or higher, you must update the firmware through DJI Assistant 2. Please see the Phantom 3 Professional / 4K section for more information.

Tap the three vertical dots in the upper-right corner and select "Camera" from the menu. Tap the "Camera Settings" icon in the upper-right corner and select "About" from the menu. Tap the "Update Firmware" button and follow the prompts.

Note: Make sure the remote controller is connected to the Internet during the update process.

Once the update is complete, power off your remote controller.

Install the firmware on your remote controller using a memory card

Note: You can use the version of DJI Assistant installed for firmware update on your mobile device or computer. Please see this post for more information. If you're updating to version 3.3.38 or higher, you must update the firmware through DJI Assistant 2. Please see the Phantom 3 Professional / 4K section for more information.

Download the Phantom 3 Standard firmware update file and unzip it. Open the folder and you should see a file named "dji_system.bin". Leave this file as it is.

Format your memory card.

Copy the "dji_system.bin" file you downloaded and paste it in. To power on the battery press the power button once, then press and hold it for two seconds. Connect your remote controller to your computer using a USB cable. Power on your remote controller.

- Flash green while you're Phantom is ready
- Flash red while your Phantom is not ready (Make sure you're Phantom is powered on and the battery is fully charged)
- Solid red when your Phantom is not ready (Make sure you're Phantom is powered on and the battery is fully charged)

Safely eject your memory card from your computer and insert it into your remote controller. Power on your remote controller and wait for the update process to complete. The process is complete when the LED on the remote controller is solid green.

Power off your remote controller and remove your memory card.

Install the firmware on your Phantom batteries

Note: You can use the version of DJI Assistant installed for firmware update on your mobile device or computer. Please see this post for more information. If you're updating to version 3.3.38 or higher, you must update the firmware through DJI Assistant 2. Please see the Phantom 3 Professional / 4K section for more information.

Download the Phantom 3 standard firmware update file and unzip it. Open the folder and you should see a file named "dji_system.bin". Leave this file as it is.

Format your memory card.

Copy the "dji_system.bin" file you downloaded and paste it in the root directory.

Power on your Phantom and connect it to your computer using a USB cable. Power on your battery by pressing the power button once, then press and hold it for two seconds. Safely eject your memory card from your computer and insert it into your battery. Power on your battery and wait for the update process to complete. The process is complete when the LED on the battery is solid green.

Power off your battery and remove your memory card.

Keep or delete the firmware SD file

Once you've updated your firmware, you can keep or delete your dji_system.bin file. If you're planning to go backwards, you'll need to keep it. Otherwise, you can delete it.

Check and/or restore all settings in the DJI GO app

Open the DJI GO app and check all of your settings and controls. Make sure they're set to your liking. Also, if you're planning to go backwards, you'll need to restore your settings from a backup. Please see this post for more information.

Recalibrate

All the following calibrations from within the DJI GO application:

- Calibrate the IMU - Level surface, Horizontal calibration
- Calibrate the compass - Vertical calibration
- Calibrate the gimbal - Level surface

Phantom 101
Buy Phantom Accessories Here | Buy Phantom Authorized Dealer | Buy Refurbished Phantoms
Phantom 1 | Phantom 2 | Phantom Vision | Phantom Vision+ | Phantom 3 Standard | Phantom 3 Advanced | Phantom 3 Professional | Phantom 4 | Phantom 4 Pro | Phantom 4 Advanced | Phantom 4 Pro V2.0 | Mavic Pro | Mavic Air | Spark
PHANTOM 3 DEALERS: Find your Authorized Phantom 3 Dealer for a price match or to view Phantom deals.
Phantom 3 Standard | Phantom 3 Advanced | Phantom 3 Professional | DJI Mavic | Firmware Updates | Flight Log Viewer
PHANTOM 3 DEALERS: Find your Authorized Phantom 3 Dealer for a price match or to view Phantom deals.

Nicholas
Posts: 1,111
Joined: Jan 2015
Reputation: 0

Sep 8, 2015 at 12:19 pm

Sep 8, 2015 at 12:19 pm

Pirate Bob
Posts: 1,111
Joined: Jan 2015
Reputation: 0

Sep 8, 2015 at 12:19 pm

Sep 8, 2015 at 12:19 pm

Pirate Bob
Posts: 1,111
Joined: Jan 2015
Reputation: 0

Sep 8, 2015 at 12:19 pm

Sep 8, 2015 at 12:19 pm

Nicholas