

## Pack List

- Phantom 3 Pro
- Battery #1 (Charged)
- Controller (Charged)
- iPad Mini 2 (Charged)
- Props (2 sets)
- Micro SD Cards
- USB Cable
- Reading Glasses
- Sun Shade for iPad
- Lanyard
- DJI Charger
- Phone for HotSpot

## Pre-Flight

- Connect USB to iPad
- Download Area Maps
- Connect Lanyard
- Remove Lens Cover
- Remove Gimbal Bracket
- Insert Micro SD Card
- Install Battery in P3P
- Install Props
- Turn On Radio
- Turn On iPad and Launch DJI Pilot app Max Volume
- Turn Off WIFI
- Place P3P at Take-Off Location (Home Point)
- Turn On P3P
- Adjust Camera Settings
- Format Micro SD Card
- Check Values:
- Compass Status
- IMU Values
- Gain Values and EXP
- Max Height
- RTH Height
- R/C EXP & Gain
- VPS On (Indoor Flight)
- Satellite Count

## Hover Check

- Check Camera View and Level
- Check for Vibrations
- Check Distance to Home Point

## Post Flight

- Turn Off P3P (First)
- Turn Off Radio
- Turn Off iPad
- Remove Props
- Install Gimbal Lock
- Install Lens Cover

### Normal

 ..... Red, Green and Yellow Flash Alternately

Turning On and Self Diagnostic Testing

 ..... Green and Yellow Flash Alternately

Warming Up

 ..... Green Flashes Slowly

Safe to Fly (P-mode with GPS and Vision Positioning)

 X2 ..... Green Flashes Twice

Safe to Fly (P-mode with Vision Positioning but without GPS)


 ..... Yellow Flashes Slowly

Safe to Fly (A-mode but No GPS and Vision Positioning)

### Warning

 ..... Fast Yellow Flashing


Remote Controller's Signal Lost

 ..... Slow Red Flashing

Low Battery Warning

 ..... Fast Red Flashing

Critical Battery Warning

 ..... Red Flashing Alternately

IMU Error

 — Solid Red

Critical Error

 ..... Red and Yellow Flash Alternately

Compass Calibration Required